

# INSTALLATION GUIDE

## UNI safety hook, type 4 for plain tiles



Fix the safety hook in to the rafter through the counter batten. Use the 4 pcs of 6x140 dormant screws for the fixing.



The shaft of the hook is fit to the counter batten and the batten. Drill two screws to the batten and the other two in to the counter batten!



Finish the tile cover and use base tiles above the safety hook!

A notice:

- The specifications of national regulations (such as ZVDH, ÖNORM or SIA standards) as well as national and European standards (such as DIN or EN) must be kept.
- The installer is responsible for the processing and installation of the products in accordance with the assembly instructions and the resulting tightness in the sub-roof.
- CREATON South-East Europe Kft. has no responsibility for damage caused by improper installation.

## Guide for the different tile models

Model	Type number	Dist. of the steel beam	Ventilation tile break out
Domino	1	150 mm	yes
Cantus	1	140 mm	yes
Ratio	1	150 mm	yes
Simpla	1	145 mm	yes
Maxima	1	150 mm	no
Rapido	2	175 mm	no
Balance	3	230 mm	no
Nomina	3	230 mm	no
Magnum	3	230 mm	no
Premion	3	230 mm	no
Futura	3	230 mm	no
Optima	3	230 mm	yes
Sinfonie	3	230 mm	yes
Melodie	3	230 mm	no
Titania	3	230 mm	yes
<b>Klassik 18x38</b>	<b>4</b>	-	-
<b>Klassik 20x40</b>	<b>4</b>	-	-
<b>Ambiente 18x38</b>	<b>4</b>	-	-
<b>Ambiente 20x40</b>	<b>4</b>	-	-
Róna szegment cut	4	-	-
Róna straight cut	4	-	-
Hortobágy	4	-	-
Heidelberg	5	150 mm	-
Göteborg	5	150 mm	-
Kapstadt	5	150 mm	-

