

INSTALLATION GUIDE

Aluminium snow guard tube



Position the aluminium base element on the batten.

Fasten the base element to the batten with the two corrosion-resistant screws provided in the package. For plain tiles use the third screw to the batten above it, through the fastening tab on the base element.

If necessary use an additional batten for the fastening tab in the required distances.

The distance between the support defined by the tile model, but it can't be more than 80 cm!

According to the calculated snow load, this distance has to be smaller and/or additional snow guard line has to be created.

The tube support must be mounted on the aluminium base element and fastened with the screw provided in the package, using a size 13 spanner.



The round tubes are passed through each snow guard support. Additional fastening is no longer necessary.

If the pipes are longer than three meters, they must be fitted with a connector.

swissporTON aluminum systems are installed on basic elements that match the shape and color of the roof tile. Step systems can be installed from a roof inclination of 10° to approx. 60° in accordance with DIN 18160-5

ⓘ The snow guard systems are forbidden to used as an anchoring point for safety harnesses.
 Note: When installing rooftop solar systems, we recommend a distance from the snow guard system of approx. 1 meter must be maintained.