

INSTALLATION GUIDE

Hip cap tile



1 The apex of the hip is the cross-point where the hips meet with the ridge



2 Position the last hip tile onto the edge and mark the line of the cut. Cut the hip tile to size along the mark using a disc cutter.



3 Cut and adjust the ridge and hip tiles in such a way that the hip cap tile is clearly supported at all three points



4 It is not necessary for the three tiles that meet at the apex to touch each other precisely. The hip cap tile has to overlap the three ridge tile by approx. 5-6 cm.



5
Position the hip cap tile onto the apex taking care not to leave too large a gap on any of the sides.



6a
Mark the overlap of the hip cap tile on the hip/ridge tiles, then bond the three hip and ridge tiles to the hip cap using a high-quality adhesive (frost-resistant and suitable for ceramics)



6b
Drill a hole in the hip cap tile then fasten it to the timber structure below using a corrosion-proof sealing screw.



7
The swissporTON hip cap tile can be used with roof pitches between 10° and approx. 52°.

The hip cap tile is available in the right shape and color for almost all ridge/hip tile models.