

INSTALLATION GUIDE

Nail in stormclip for side interlocking plain tiles



Hook the stormclip into the lower part of the side lock of the tile. The flat stem has to rest on the tile below.



Hammer the nail that stands out from the body of the stormclip into the batten holding the tile below.



The number and layout of stormclips must be determined according to valid standards and regulations.